


## Wiring instructions


### NY3 12V DC TIMER RELAY (12V DC ONLY)



NY WHOLESALE INTERCOM GROUP  
www.NYWINT.COM - PH# (516) 387-6606

## Wiring instructions

### NY4 24V DC TIMER RELAY



NY WHOLESALE INTERCOM GROUP  
www.NYWINT.COM - PH# (516) 387-6606